

ASSEMBLY INSTRUCTIONS

PARTS INCLUDED

1. WOODEN TOP
2. 4 WOODEN LEGS
3. 8 SCREWS 8 WASHER
4. 1 ALLEN KEY



1. Place the wooden top upside down (on a protective matt).
2. Attach the wooden legs to the top 1 by 1 as per the picture & tighten the screws with the help of allen key,



3. After attaching all legs make sure they are fixed firmly and not shaking.



4. Overturn the bench carefully.

