










## NEWPORT ENTERTAINMENT CENTER

# NEWPORT









## ASSEMBLY INSTRUCTIONS



## PARTS LIST

LABEL	PICTURE	DESCRIPTION	QTY
A		TV Console	1
B		Left/ Right Buffet	2
C		Left/ Right Hutch	2
D		Top	1
E		Shelf	1
F		Back Panel	1

## HARDWARE

LABEL	PICTURE	DESCRIPTION	QTY
1		Bolt M6 x 35mm	8
2		Spring Washer Ø6/12 x H1.5mm	8
3		Flat Washer Ø6/16 x H1.5mm	8
4		Allen Key 4mm	1
5		Flat head Screws M3 x 15mm	4
6		Rounded head Screws M3 x 20mm	12
7		Anti Tip Kit	2
8		Button Ø10	12



Read instructions cover to cover



Have two adults on hand for assembly




Do not assemble on flooring or carpet. Assemble on a clean non-marring surface (ex: packing foam)




Save all packaging until assembly is completed

## ASSEMBLY STEPS


### STEP 1




### STEP 2




STEP 3







STEP 4




STEP 5



**STEP 6**



**STEP 7**



Finish the installation before plugging into the outlet.