Assembly Model: **B5520-K-HBFB** + **B5520-KQ-Rail** Instructions STEP 3 (BOX 1) Box of Headboard (BOX 1) Box of Headboard (Hardware List) Descriptions Descriptions NO. Qty. NO. Qty. Attach the Center Slat (I), Bed Slat With Stopper (F) & Bed Slat (G) to Slat Support (E). Tighten with JCBC Screw M6 x50mm Headboard Panel JCBC M6 x 50mm (1) by using L Key M4 (5). Headboard Leg Right (R) JCBC Screw M6 x30mm Headboard Leg Left (L) Spring Washer Ø 1/4" 010 D Footboard Panel Flat Washer Ø 1/4" x 13mm Slat Support 5 CSK M4 x 16mm 18 2 4 CSK M4 x 32mm 10 Bed Slat (With Stopper) G Bed Slat 3 5 L Key M4 Slat Panel L Key M5 6 (BOX 2) Box of Side Rail Descriptions Qty. Slat Panel 5 Center Slat Side Rail Tighten Bed Slat With Stopper (F) & Bed Slat (G) to Side Rail (J) with CSK M4 x 32mm (4). STEP 1 STEP 4 Close the distance Slat Panel (H) to stopper at Bed Slat With Stopper (F). Tighten Slat Panel (H) to Bed Slat With Stopper (F) with CSK M4 Attach the Headboard Leg (B) /(C) by using JCBC x 16mm(3). Screw M6 x 30mm, SpringWasher Ø 1/4", Flat Washer Ø 1/4" x 13mm (2) through the pre-drilled hole of Headboard Leg (B) / (C) and tighten by using L Key 'L" Marking behind the **Please note the marking on the leg and headboard** (H) Headboard & Leg Attach the Slat Panel (H) to top Bed Slat With Stopper (F) & Bed Slat (G) "R" Marking (B) behind the **COMPLETED** Headboard & Les **ASSEMBLY** STEP 2 Attach the Side Rail (J) to Headboard Leg (B/C). Tighten screw on Headboard Leg (B/C) by using L Key M5 (6) & repeat the same step on Footboard Leg (D)