ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

| PART LIST | | | |
|-----------|------------------------------------|--------|--|
| ITEM | DESCRIPTION | QTY | |
| Α | HEADBOARD | 1 PC | |
| В | FOOTBOARD | 1 PC | |
| C | SIDE RAIL | 2 PCS | |
| D | CENTER RAIL | 2 PCS | |
| E | CENTER SUPPORT | 3 PCS | |
| F | CENTER SUPPORT LEG | 6 PCS | |
| G | BED SLAT | 39 PCS | |
| Н | BED LEG | 4 PCS | |
| I | HEADBOARD & FOOTBOARD SUPPORT WOOD | 2 PCS | |

| HARDWARE LIST | | | |
|---------------|---------------------------|-------------------|--------|
| ITEM | DESCRIPTION | | QTY |
| 1 | JCBC BOLT M6 x 40mm | aaaaac i (| 4 PCS |
| 2 | JCBB BOLT M8 x 40mm | aamama —(•) | 6 PCS |
| 3 | WOOD SCREW M3.5 x 16mm | (1 | 12 PCS |
| 4 | WOOD SCREW M4 x 20mm | € | 4 PCS |
| 5 | M8 FLAT WASHER | 0 | 6 PCS |
| 6 | M8 SPRING WASHER | 0 | 6 PCS |
| 7 | BED SLAT SIDE FITTER | | 26 PCS |
| 8 | BED SLAT CENTER FITTER | \Diamond | 26 PCS |
| 9 | M4 ALLEN KEY (BALL SHAPE) | L | 1 PC |
| 10 | M5 ALLEN KEY (BALL SHAPE) | | 1 PC |
| | · | | |





