

Product Installation

1. Find out 4 foots in the carton
2. Overturn the ottoman, there are 4 holes
3. Lock the foots to ottoman properly

