

ASSEMBLY INSTRUCTIONS

MODEL#: 4551 (07/2015) (V#12600TY11)

**NOTE: THIS ITEM IS NOT RECOMMENDED FOR COMMERCIAL USE
KEEP THIS DOCUMENT FOR REFERENCE IN CASE PARTS ARE NEEDED**

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED! !

No	DESCRIPTION	MEASURE	Q'TY
A	CHAIR BACK	38" X17" X2-1/2"	1PC
B	CUSHION	18-1/2" X18" X2-1/2"	1PC
C	CHAIR LEG-L	15-3/4" X17" X2"	1PC
D	CHAIR LEG-R	15-3/4" X17" X2"	1PC
E	CONNECTING TUBE	15-3/8" X1" x1/2"	1PC
F	BOLT	1/4" X12mm	8PCS
G	WOOD SCREW	M4X16mm	4PCS
H	ALLEN KEY	1/4"	1PC

