

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 302351KE (B1-B3) Eastern King Bed

REVISION 0 : 05/16/2019

PAGE 1 OF 5

COASTERFURNITURE.COM

# ITEM: 302351KE (B1-B3)

## ASSEMBLY INSTRUCTIONS



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.







## **PARTS IDENTIFICATION**

### **B1 (BOX 1)**


Α

В

С

D

**HEADBOARD** 1PC B2 (BOX 2) FOOTBOARD 1PC **B3 ( BOX 3) BED SLAT** 5PCS



**BED SLAT** Ε SUPPORT WITH LEVELER

**BED RAIL** 

10PCS

2PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



# ITEM:302351KE (B1-B3)

### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

## **HARDWARE IDENTIFICATION**

### Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 302351KE (B3)

| 1 | ALLEN WRENCH<br>(Φ6 - BLK)             |   | 1PC   |
|---|--|---|-------|
| 2 | SHORT BOLT<br>(Ф6 X 30mm - RBW)        |   | 8PCS  |
| 3 | LONG BOLT<br>(Ф6 X 40mm - RBW)         |   | 10PCS |
| 4 | FLAT HEAD SCREW<br>(Φ4 X 32mm - RBW)   |   | 10PCS |
| 5 | LOCK WASHER<br>(Ф6 - RBW)              | Ŷ | 8PCS  |
| 6 | FLAT WASHER<br>(Ф7 X 19mm X 2.0 - RBW) | 0 | 8PCS  |
| 7 | LEVELER<br>(M6 x 23mm - RBW)           |   | 10PCS |
| 8 | BARREL NUT<br>(Φ6 X 13 - RBW)          |   | 10PCS |

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



# ITEM:302351KE (B1-B3)



## ASSEMBLY INSTRUCTIONS

## <u>STEP 1</u>

