





ASSEMBLY INSTRUCTIONS | LOOM DINING CHAIR

HARDWARE CHECKLIST		
A		JCBC Bolts M6x50mm (4pcs)
B		Flat Washers (4pcs)
C		Spring Washers (4pcs)
D		Allen Key (1pc)

Step 1

