

# ASSEMBLY INSTRUCTIONS | LOOM OUTDOOR DINING CHAIR

PARTS CHECKLIST		
A		JCBC Bolts M6x50mm (4 pcs)
B		Flat Washers (4 pcs)
C		Spring Washers (4 pcs)
D		Allen Key (1 pc)

## Step 1

