PAGE 2 OF 2

ITEM: 7908 T

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by side
- 2.Please check to see that all hardware and parts are present prior start of assembly
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly



Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establiahment.

PARTS IDENTIFICATION

HEADBOARD 1PC

BED RAIL 2PCS

BED SLAT 12PCS

HARDWARE IDENTIFICATION

1	BOLT		8 PCS
2	FLAT WASHER		8 PCS
3	ALLEN WRENCH		1 PC
4	FLAT HEAD SCREW		8 PCS