







JOFRAN INC.

ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION MODEL # 1706-78 MADISON COUNTY VINTAGE WHITE SOFA CONSOLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Parts key			
No	Code	Qty	Description
1		1 Pc	Complete Table Top
2	1706-78P02R	1 Pc	Right Front Leg
3	1706-78P02L	1 Pc	Left Front Leg
4	1706-78P02RB	1 Pc	Right Back Leg
5	1706-78P02LB	1 Pc	Left Back Leg
6		1 Pc	Stretcher
7		2 Pcs	Storage Box
8	1706P01F	4 Pcs	Floor Glide
9	1706P01AT	1 Set	Anti - tip kit

Hardware kit # 1706-78P01			
No	Description		Qty
A		Hex nut Ø8	8 pcs
B		Bolt Ø6.3x30	12 pcs
C		Lock washer Ø8.5	20 pcs
D		Flat washer Ø8.5	20 pcs
E		Allen key	01 pc
F		Key wrench	01 pc

STEP 1

- Carefully lay the Complete Table Top (1) on a smooth flat surface to prevent scratches.
- Attach the legs of table (2), (3), (4) and (5) to the appropriate positions.
Using the Hex nuts (A), Lock washer (C) and Flat washer (D). (See Detail A)
- Then, attach the Stretcher (6) to the two rear mounts of 2 legs (4) and (5).
Using the Bolt (B), Lock washer (C) and Flat washer (D). (See Detail B)
- Using the Key Wrench (F) and the Allen Key (E) tighten all the Hex nuts and Bolts.

