

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Hardware kit (1931-385KDP46)			
No	Description		Q'Ty
A		Lock Washer 5/16"	11 pcs
B		Flat Washer 5/16"	11 pcs
C		Long Bolt 1/4" x 3"	4 pcs
D		Medium Bolt 1/4" x 2"	4 pcs
E		Short Bolt 1/4" x 1.5"	3 pcs
F		Allen Key	1 pc
G		Screw Ø4 x 38mm	4 pcs

Key Parts			
No	Code	Description	Q'Ty
1	1931-385KDP40	Chair Back	1 pc
2	1931-385KDP41	Complete Seat	1 pc
3	1931-385KDP42	Right Facing Leg	1 pc
4	1931-385KDP43	Left Facing Leg	1 pc
5	1931-385KDP44	Right Stretcher	1 pc
6	1931-385KDP45	Left Stretcher	1 pc
7	1931P01F	Floor glide	4 pcs

Remove bottom seat material before setup

FABRIC CARE : CLEANING CODE "S"

Clean only with dry cleaning slovent ,do not saturate.Do not use water.

Pile fabrics may require brushing to restore appearance.

FABRIC CONTENT:55% Cotton; 45% Linen

STEP 1

- Carefully lay Chair Back flat on a smooth flat surface to prevent scratches.

- Affix Complete Seat to Chair Back by inserting a Flat Washer (B), Lock Washer (A) with Short Bolt (E) into each of the holes on the back rail of the seat, and Long Bolt (C) with washes into each of 2 holes in the Complete Seat corners. (See Detail A & B).

- Tighten screws with provided Allen Key (F) by turning clockwise until secure

STEP 2

- Carefully turn chair upside down and attach each Front Leg to the front corners of the Complete Seat (Keeping in mind of the right side and left side leg) with a Flat Washer (B), Lock Washer (A) and Medium Bolt (D). (See detail C). Keep the bolt loose at this point. Insert right side stretcher and left side stretcher between the Front and Back Legs. Fasten stretchers to legs with Screws (G) using a Screwdriver (not provide).

- Be sure to level the chair prior to tightening front leg bolts with wrench provided (F).

