



·Always start connecting from the end pieces and work inward toward the corner wedge.

