furniture

Progressive® ASSEMBLY INSTRUCTION

Model No: B123-34/35/78 QUEEN BED



IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws / bolts until all completely assembled.
- Keep all hardware parts out of reach of children!
- Tighten screws periodically! With the use of this product bolts and screws may become loose over time!
- Don't attempt to modify parts!

PART LIST					
NO	DE	SCRIPTION	QTY/PCS		
1		HEADBOARD	1 PC		
2		FOOTBOARD	1 PC		
3		SIDE RAIL	2 PCS		
4		SLAT	4 PCS		
5	-	SUPPORT LEG	4 PCS		

HARDWARE LIST				
NO		DESCRIPTION QTY/PCS		
A		BOLT M8 x 25mm	8 PCS	
В	8	SPRING WASHER M8	8 PCS	
С	0	FLAT WASHER M8	8 PCS	
D		ALLEN KEY M5	1 PC	
E	<()	CSK SCREW M4 x 32mm	8 PCS	

REMARKS: YOU WILL ALSO NEED A PHILIP SCREW DRIVER (NOT PROVIDED)

