

ANTI-TIP KIT

ASSEMBLY INSTRUCTIONS

TECHNICAL SPECIFICATION
ANTI-TIP KIT
DESCRIPTION: ANTI-KIT

Anti-tipping Restraint Instructions

1. When properly installed this hardware can provide protection against the unexpected tipping of furniture.
2. Attach one of the mounting brackets (D) and secure to the back top edge of the furniture using the short screw (E).
3. Mark the location on the wall for mounting the second bracket (D). Create the appropriate sized hole in the wall and insert the plastic screw anchor (C). Secure the bracket to the wall using the long screw (B). Other fixings may be required depending on wall type.
4. Place the furniture so the bracket on the back edge of unit is line with the bracket on the wall.
5. Lace an end of the nylon restraint strap (A) down through each bracket. Bring both ends together and slide the beaded end of the strap through the keyhole shaped slot on the other end. Pull down on the beaded end until it snap-locks into the keyhole.
6. Check to make sure the strap is securely laced and locked to the brackets.

Important safety instructions:

- * Please carefully read all instructions before assembling.
- * For your safety, assembly by two or more adults is recommended.
- * Keep instructions for future use.

Pre-assembly:

- * Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts of hardware.
- * Remove parts and hardware from box along with any plastic protective packaging.

Hardware

1. 2 nylon strap
2. 2 long screw
3. 2 plastic screw anchor
4. 4 wall brackets
5. 2 short screw

