ASSEMBLY INSTRUCTIONS

Kit Contents:-

1.Bolts-1Pc. 25x9mm.







4.Spanner-1Pc.

5.Spanner-1Pc. 14-15no.



Instructions:

- 1. Place headboard against the wall and lossen the inserted bolts.
- 2. Place foot board upside down as shown in picture 2 & match the legs hole with foot board bottom holes. Secure using bolts & washers using spanner. (Using 25x8mm. bolts)
- 3. Place the side rails on headboard and tighten the bolts. Repeat the same on foot board side as shown in picture 3. (Using 25x9mm. bolts)
- 4. Similarly match the headboard & foot board with center support & fix the center support as shown in picture 4.
- 5. Place the slats between center support & side rail as shown picture 5.
- 6. Now the bed is ready to use as shown picture 6.

