











Assembly Instruction for ROUND TABLE 2074T-60

Caution: Please read instruction thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please Put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST			
NO		PART DESC	Q.TY
A		TABLE TOP	1
B		PANEL CONNECTOR	1
C		TOP LEG	1
D		BOTTOM LEG	1
E		LAZY SUSAN	1


HARDWARE LIST			
NO		HARDWARE DESC	Q.TY
1		ALLEN BOLT (5/16*35mm)	16
2		ALLEN BOLT (5/16*75mm)	1
3		SPRING WASHER (5/16)	17
4		FLAT WASHER (5/16*19*1.5mm)	17
5		ALLEN KEY (M5*100mm)	1

NOTES: DON'T FULLY TIGHTEN ANY BOLTS UNTIL LAST STEP

STEP 1




STEP 2




Assembly Instruction for
ROUND TABLE
2074T-60


STEP 3



STEP 4



STEP 5



STEP 6: Completed

