








# ASSEMBLY INSTRUCTIONS

3629EC-C MEDIA CONSOLE  
 BEFORE YOU START ASSEMBLING  
 PLEASE MAKE SURE ALL PARTS & HARDWARE ARE INCLUDED IN BOX :

## PART LIST

NO	DESCRIPTION	SKETCH	QTY
1	MEDIA CONSOLE		1 Pc

## HARDWARE LIST

NO	SKETCH	HARDWARE	QTY
A		Screw Ø8 x 2"	1 Pc
B		Screw Ø8 x 3/4"	1 Pc
C		Metal Anchor	2 Pcs
D		Restrain Strap	1 Pc
E		Fischer	1 Pc
F		Philip Headscrew driver (not included)	

MANDATORY

