





# ASSEMBLY INSTRUCTIONS #3648-A





PART LIST		SKETCH	QTY
NO	DESCRIPTION		
1	MEDIA CONSOLE		1 Pc

HARDWARE LIST			
NO	SKETCH	HARDWARE	QTY
A		Screw Ø8 x 2"	1 Pc
B		Screw Ø8 x 3/4"	1 Pc
C		Metal Anchor	2 Pcs
D		Restrain Strap	1 Pc
E		Fischer	1 Pc
F		Screw Ø8 x 1 1/4"	8 Pcs
G		Support Fireplace left	1 Pc
H		Support Fireplace right	1 Pc
I		Philips Head screw driver (not included)	
J		Fireplace (not included)	



# ASSEMBLY INSTRUCTIONS #3648-A



PART LIST		SKETCH	QTY
NO	DESCRIPTION		
1	MEDIA CONSOLE		1 Pc

HARDWARE LIST			
NO	SKETCH	HARDWARE	QTY
A		Screw Ø8 x 2"	1 Pc
B		Screw Ø8 x 3/4"	1 Pc
C		Metal Anchor	2 Pcs
D		Restrain Strap	1 Pc
E		Fischer	1 Pc
F		Screw Ø8 x 1 1/4"	8 Pcs
G		Support Fireplace left	1 Pc
H		Support Fireplace right	1 Pc
I		Philips Head screw driver (not included)	
J		Fireplace (not included)	