




ASSEMBLY INSTRUCTIONS #3650

PART LIST

NO	DESCRIPTION	SKETCH	QTY
1	MEDIA CONSOLE		1 Pc

HARDWARE LIST

NO	SKETCH	HARDWARE	QTY
A		Screw Ø8 x 2"	1 Pc
B		Screw Ø8 x 3/4"	1 Pc
C		Metal Anchor	2 Pcs
D		Restrain Strap	1 Pc
E		Fischer	1 Pc
F		Screw Ø8 x 1"	8 Pcs
G 1		Support Fireplace left	1 Pc
G 2		Support Fireplace right	1 Pc
H		Philip Headscrew driver (not included)	
I		Fireplace (not included)	



ASSEMBLY INSTRUCTIONS #3650

PART LIST

NO	DESCRIPTION	SKETCH	QTY
1	MEDIA CONSOLE		1 Pc

HARDWARE LIST

NO	SKETCH	HARDWARE	QTY
A		Screw Ø8 x 2"	1 Pc
B		Screw Ø8 x 3/4"	1 Pc
C		Metal Anchor	2 Pcs
D		Restrain Strap	1 Pc
E		Fischer	1 Pc
F		Screw Ø8 x 1"	8 Pcs
G 1		Support Fireplace left	1 Pc
G 2		Support Fireplace right	1 Pc
H		Philip Headscrew driver (not included)	
I		Fireplace (not included)	

