

# Assembly Instructions







## ASSEMBLY TIPS:

1. Remove hardware from plastic bag and sort by size.
2. Please check to see that all hardware and parts are present prior to assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





## Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.





## PARTS IDENTIFICATION:

DESCRIPTION	FIGURE	Q, TY
A Clump weight		1PC
B U Tube		1PC
C MAIN POST		1PC
D ARMS		1PC
E SHADE		4PCS
F SOCKET RING		4PCS

## HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	QTY
1	Cross head screw		4PCS
2	Washer		4PCS
3	Nut with cap		4PCS
7	Wrench		1PC

## PRE-INSTALLED HARDWARE

4	Silver NUT		1PC
5	Spring Washer		1PC
6	Flat Washer		1PC
8	Tapping Screw		1PC
9	Hollow Screw		1PC

