ASSEMBLY INSTRUCTIONS

ITEM NO: B5201CL & B5201WH-Q-FB/B5201CL & B5201WH-KQ-RAIL/ B5201CL & B5201WH-Q-HBWG QUEEN BED

(BOX 1) BOX OF FOOTBOARD


ITEM	DRAWING	DESCRIPTION	QTY
A		FOOTBOARD DRAWER	1
В	9	BED LEG	18
C		WOODEN SLAT	4
D	Ů	WOODEN SUPPORT WITH ADJUSTER	4

(BOX 2) BOX OF SIDE RAIL

ITEM	DRAWING	DESCRIPTION	QTY
E		SIDE RAIL DRAWER (L/R)	2

(BOX 1) HARDWARE LIST

HAKDWAKE LIST					
DRAWING	DESCRIPTION	QTY			
	ALLEN KEY (M4)	1			
(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	CONNECTION BOLT (M6 x 35mm) W/SPRING WASHER & WASHER MEDIUM	18			
0	CONNECTION BOLT (M6 x 40mm)	4			
(S)mmmm	CSK SCREW (M4 x 32mm)	24			
	PLASTIC DOWEL (M8 x 30mm)	4			
	SCREW DRIVER (*)	1			
		ALLEN KEY (M4) CONNECTION BOLT (M6 x 35mm) W/SPRING WASHER & WASHER MEDIUM CONNECTION BOLT (M6 x 40mm) CSK SCREW (M4 x 32mm) PLASTIC DOWEL (M8 x 30mm)			





(BOX 3)

BOX OF HEADBOARD WING


DOTT OF THE IDDOTTED WITH					
ITEM	DRAWING	DESCRIPTION	QTY		
F		HEADBOARD WING (L/R)	2		

STEP 1 STEP 2 Marking Line Marking Line

THE HARDWARE IS LOCATED IN THE PACKING ITEMS.

NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.

CLEANING INSTRUCTION




THE HARDWARE IS LOCATED IN THE PACKING ITEMS.

NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.

CLEANING INSTRUCTION

ITEM NO: B5201CL & B5201WH-Q-FB/B5201CL & B5201WH-KQ-RAIL/ B5201CL & B5201WH-Q-HBWG QUEEN BED



THE HARDWARE IS LOCATED IN THE PACKING ITEMS.

NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.

CLEANING INSTRUCTION