
Assembly Instructions **CROWN MARK (CRWN)**

MODEL:B6580-7 JAYMES TV STAND

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with hardware STEP 1

list as below:

(BOX 1) BOX OF DRESSER			
ITEM	DRAWING	DESCRIPTION	QTY
Α		TV STAND	1
В		LEG SUPPORT	2



Step 1: Attach and tighten the Support Leg (B) to the TV Stand (A) as shown.

NOTE:MUST TIGHTEN SCREW PERIODICALLY.WITH USE SCREWS WILI BECOME LOOSE CHECK THIGHT OF ALL SREWS EVERY 6-8 WEEKS CLEANING INSTRUCTION

THE ANTI TIPPING HARDWARE IS LOCATED IN THE RIGHT SIDE FRONT BOTTOM TV STAND DRAWER

COMPLETED **ASSEMBLY**