+ H/F CANOPY BARS

B8250 - Q - BASE SIENNA QUEEN BASE

B8250 - KQ - RAIL SIENNA K/Q RAIL + SIDE CANOPY

+POST

ASSEMBLY INSTRUCTIONS

(BOX 1) BOX OF HEADBOARD & FOOTBOARD

ITEM	DRAWING	DESCRIPTION	QTY
A		HEADBOARD FRAME	1
В		FOOTBOARD FRAME	1
С	Ů	WOODEN SUPPORT	4
D		WOODEN SLAT	4
E		TOP RAIL	2

(BOX 2) BOX OF PANEL


ITEM	DRAWING	DESCRIPTION	QTY
F		CONCEAL PANEL	5

(BOX 3) BOX OF SIDE RAIL

ITEM	DRAWING	DESCRIPTION	QTY
G1		LEFT HEADBOARD LEG	1
G2		RIGHT HEADBOARD LEG	1
H1		LEFT FOOTBOARD LEG	1
Н2		RIGHT FOOTBOARD LEG	1
I		SIDE RAIL	2
J	/	SIDE RAIL	2

(BOX 1) HARDWARE LIST

ITEM	DRAWING	DESCRIPTION	QTY
1		ALLEN WRENCH (M4 x 110mm)	1
2		WOOD DOWEL (M10 x 40mm)	18
3	330	CONNECTION BOLT (M6 x 70mm) (FOR HB & FB POST)	18
4	9 39	CONNECTION BOLT (M6 x 50mm) (FOR SR)	4
5	0	ROUND HEAD SCREW (M4 x 20mm)	20
6	Dumm	FLAT HEAD SCREW (M4 x 32mm)	8
7		SCREW DRIVER(*)	1





THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE : MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.


+ H/F CANOPY BARS

B8250 - Q - BASE SIENNA QUEEN BASE


B8250 - KQ - RAIL SIENNA K/Q RAIL + SIDE CANOPY

+POST

ASSEMBLY INSTRUCTIONS







THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE : MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.


+ H/F CANOPY BARS

B8250 - Q - BASE SIENNA QUEEN BASE

B8250 - KQ - RAIL SIENNA K/Q RAIL + SIDE CANOPY

+POST





THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE : MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.


+ H/F CANOPY BARS

B8250 - Q - BASE SIENNA QUEEN BASE

B8250 - KQ - RAIL SIENNA K/Q RAIL + SIDE CANOPY

+POST

ASSEMBLY INSTRUCTIONS



THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE: MUST TIGHTEN SCREWS PERIODICALLY, WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.


+ H/F CANOPY BARS

B8250 - Q - BASE SIENNA QUEEN BASE

B8250 - KQ - RAIL SIENNA K/Q RAIL + SIDE CANOPY

+POST

ASSEMBLY INSTRUCTIONS



THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE : MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.