Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTION: 1. Do not FULLY - TIGHTEN the nuts or nuts bolts until they are ready for assembly.

- 2. Do not OVER TIGHTEN the nuts or bolts to avoid causing damages to the thread.
- 3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tools needed: Screwdriver (not provided).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
A	HEADBOARD	1	1 PC	
В	FOOTBOARD	2	1 PC	
С	BED LEG	2	4 PCS	
D	SIDE RAIL	2	2 PCS	
E	CENTER RAIL	2	1 PC	
F	CENTER SUPPORT LEG	2	3 PCS	
G	BED SLAT	3	1 SET	

HARDWARE LIST (BOX : 2)				
ITEM	DESCRIPTION		QTY	
1	JCBC BOLT M6 x 30mm	((((((((((((((((((((((((((((((((((((2 PCS	
2	JCBC BOLT M6 x 20mm	common □	6 PCS	
3	M6 SPRING WASHER	0	8 PCS	
4	M6 FLAT WASHER	0	8 PCS	
5	M8 SPRING WASHER		4 PCS	
6	WOOD SCREW M4 x 20mm		16 PCS	
7	WOOD SCREW M4 x 38mm		9 PCS	
8	5/16" HEX NUT	0	4 PCS	
9	VMB 3087 (BLACK)		4 PCS	
10	SPANNER (13mm)	A	1 PC	
11	M4 ALLEN KEY (BALL SHAPE)		1 PC	
12	M5 ALLEN KEY (BALL SHAPE)		1 PC	







