Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

 $CAUTIONS: 1. \ Do \ not \ FULLY - TIGHTEN \ the \ nut \ or \ nut \ bolt \ until \ all \ nut \ or \ bolt \ is \ ready \ assembed.$ 

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & Rubber Mallet (not provider).

PART LIST					
ITEM	DESCRIPTION	BOX	QTY		
Α	HEADBOARD	1	1 PC	l	
В	HEADBOARD LEG	2	2 PCS	l	
С	FOOTBOARD	1	1 PC	1	
D	SIDE RAIL	2	2 PCS	l	
E	CENTER RAIL	2	1 PC	l	
F	CENTER SUPPORT LEG	2	3 PCS	l	
G	BED SLAT	3	1 SET	1	

HARDWARE LIST (BOX : 2)					
ITEM DESCRIPTION					
1	JCBC BOLT M6 x 40mm accord €	1 PC			
2	JCBC BOLT M6 x 60mm (distribution)	8 PCS			
3	M6 BEND WASHER 3013 (RB)	8 PCS			
4	WOOD SCREW M4 x 32mm	8 PCS			
5	WOOD DOWEL M8 x 30mm	4 PCS			
6	M4 ALLEN KEY (BALL SHAPE)	1 PC			
	1 2 3 4 5	ITEM   DESCRIPTION   1   JCBC BOLT M6 x 40mm   2   JCBC BOLT M6 x 60mm   3   M6 BEND WASHER 3013 (RB)   4   WOOD SCREW M4 x 32mm   5   WOOD DOWEL M8 x 30mm			





