



Parts list

AX1



BX1




CX6




DX6



STEP 1



STEP 2



STEP 3

