


## ( L-BRACKET FRONT RAIL )

(This assembly method also apply to 2 seater and 3 seater)

1.



Attach the backrest (P1) and front rail (P2) between the handle (P3).

You will need to use hardware:

- A = 4pcs
- C = 1pcs
- D = 4pcs
- E = 4pcs
- F = 1pcs


### WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this sofa if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.
- Please do not tighten the unit until fully set up for the easy of parts installation.

### PART LIST

P1		Backrest	= 1pcs
P2		Front Rail	= 1pcs
P3		Handle	= 2pcs
P4		Seat	= 1pcs

2.



Put the seat (P4) down and fix it with backrest (P1) and front rail (P2) .

You will need to use hardware:

- B = 4pcs (1 seater)
- 8pcs (2 seater)
- 12pcs (3 seater)

### HARDWARE LIST

A		M6 x 50mm JCBC	4pcs
B		WOOD SCREW M 4x 32 (1S) 4pcs (2S) 8pcs (3S) 12pcs	
C		ALLEN KEY M4	1pcs
D		WOOD BUTTON	4pcs
E		M8 x 16mm JCBB	4pcs
F		ALLEN KEY M5	1pcs

## FULLY SET UP

