BUTLER

SPECIALTY COMPANY 8200 SOUTH CHICAGO AVE.,CHICAGO,IL60617

PACKAGED

(G) Middle shelf 1pc (H) Bottom shelf 1pc (I) Side frame 2pcs (J) Back Panel 2pcs Assembly Instructions Style Number 3044



Read all instructions before starting assembly.

Step#1 Check all the components listed in _ packaged are included. Carefully lay Top Shelf (F) upside down on a flat and protected work surface being careful not to scratch the finish.


Step#2 Attach the Middle Shelf (G) to the Side Frame (I) with Bolt (A), Lock Washer (B), Flat Washer (C) and Allen Wrench (D). Repeat procedure for the other Side Frame (I) and leave the Bolts (A) loosely tighten.


Step#3 Attach the Bottom Shelf (H) to the Side Frame (I) with Bolt (A) , Lock Washer (B) , Flat Washer (C) and Allen Wrench (D) . Repeat procedure for the other Side Frame (I) and leave the Bolts (A) loosely tighten.

Step#4 Attach the assembled Side Frames (1) with shelf to the wood cleat at the side of Top Shelf (F) with Bolt (A), Lock Washer (B), Flat Washer (C) and Allen Wrench (D) and leave the Bolts (A) loosely tighten.

Step#5 Assemble the Back Panels (J) by using Screws (E) and screwdriver. Then attach them to the back of product with Screws (E) and loosely tighten.

Step#6 Tighten all the Bolts and Screws securely. Step#7 Turn the assembled unit over.





(*) Caution: DO NOT OVERTIGHTEN.

In any correspondence regarding this product, please include the complete Butler identification number located on the underside of the product.

We hope this bookcase will be a useful and decorative addition to your home for years to come.

Copyright © Butler Specialty Company, 06/11