

BUTLER

Assembly Instructions
3923011
GAME TABLE ANTIQUE CHERRY

SPECIALTY COMPANY
8200 SOUTH CHICAGO AVE. CHICAGO, IL 60617


PACKAGED

(A) 1 - Top
(B) 4 - Legs
(C) 4 - Ashtray


Read all instruction before starting assembly.

Remove all the content from the package checking that all of the component listed in "Packaged" are included. Prepare a flat, protected work surface where the product can be assembled.

Step #1



Step #2



(*) Caution : DO NOT OVERTIGHTEN.

In any correspondence regarding this product, please include the complete Butler identification number located on the underside of the product.

We hope this product will be a useful and decorative addition to your home for years to come.


Copyright © Butler Specialty Company, 11/17

BUTLER


Assembly Instructions
3923011
GAME TABLE ANTIQUE CHERRY

SPECIALTY COMPANY
8200 SOUTH CHICAGO AVE. CHICAGO, IL 60617


Option Chess Game Table



Option Dice Game Table



Option Reguler Table



(*) Caution : DO NOT OVERTIGHTEN.

In any correspondence regarding this product, please include the complete Butler identification number located on the underside of the product.

We hope this product will be a useful and decorative addition to your home for years to come.

Copyright © Butler Specialty Company, 11/17