









Loveseat and Coffee Table  
CO7330



# PART LIST


<p><b>A</b></p> 	<p><b>B</b></p> 	<p><b>C</b></p>  <p>(loveseat)</p>	<p><b>D</b></p> 	<p><b>E</b></p> 
<p>Back Panel 1 PC</p>	<p>Seat Panel 1 PC</p>	<p>Center Leg 1 PC</p>	<p>Seat Cushion 1 PC</p>	<p>Back Cushion 4 PCS</p>
<p><b>F</b></p> 	<p><b>G</b></p>  <p>(coffee table)</p>			
<p>Top Panel 1 PC</p>	<p>Leg 4 PCS</p>			

# HARDWARE LIST

<p><b>#1</b></p>  <p>M6*15mm</p>	<p><b>#2</b></p>  <p>M6*40mm</p>	<p><b>#3</b></p>  <p>M6mm</p>	<p><b>#4</b></p>  <p>M6mm</p>
<p>Short Bolt 20 PCS (Extra 2)</p>	<p>Long Bolt 4 PCS (Extra 1)</p>	<p>Flat Washer 24 PCS (Extra 2)</p>	<p>Allen Wrench 1 PC</p>

Step 1. Lay back panel (part A) down on a soft flat surface, such as carpet, as shown below. Attach seat panel (part B) to back panel (part A) using long bolts (part #2), flat washers (part #3) and allen wrench (part #4).


NOTE: Please fully tighten all bolts at this time.




Step 2. Attach center leg (part C) to seat panel (part B) using short bolts (part #1), flat washers (part #3) and allen wrench (part #4).

NOTE: Please fully tighten all bolts at this time.

It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.



Step 3. Carefully turn unit upright. Place seat cushion (part D) and back cushions (part E) as shown below.




Step 4. Lay top panel (part F) down on a soft flat surface, such as carpet, as shown below.

Attach legs (part G) to top panel (part F) using short bolts (part #1), flat washers (part #3) and allen wrench (part #4).

NOTE: Please fully tighten all bolts at this time.

It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.



Step 5. Carefully turn assembled unit upright on a flat surface.

