

COASTER®

Fine Furniture

506023

CHAIR

ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



www.coastercompany.com

2017/08/10


ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME PER UNIT: 2 MINUTES

PARTS IDENTIFICATION



H CHAIR



1PC

B LEG




4PCS

C BACK CUSHION



1PC

D SEAT CUSHION




1PC

Z		HARDWARE PACKAGE	
NO	DESCRIPTION	FIGURE	QTY
1	PLASTIC GASKET 5/16" * 49mm		4PCS

STEP 1 → 2

STEP 1

1		X 4
---	---	-----



STEP 2

