



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**506571
SOFA**

REVISION 0: 05/12/2017
REVISION 1: 05/08/2019

COASTERFURNITURE.COM

ITEM: 506571

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION


A



BASE

1PC

B



BACK

1PC

C



LEG


4PCS

ITEM: 506571




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3



STEP 4

