


*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

723139  
**SOFA TABLE**

ITEM: 723139



# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 35 MINUTES

## PARTS IDENTIFICATION

A	TOP		1PC
B	LEFT FRAME		1PC
C	RIGHT FRAME		1PC
D	FRONT CROSSBAR		1PC
E	BACK CROSSBAR		1PC
F	BOTTOM CROSSBAR		1PC
G	SUPPORT CROSSBAR		3PCS
H	HANDLE		2PCS


## HARDWARE IDENTIFICATION

1	SHORT BOLT (1/4" x 15mm SR)		18PCS
2	LONG BOLT (1/4" x 55mm SR)		6PCS
3	HANDLE BOLT (1/4" x 32mm SR)		4PCS
4	HANDLE BOLT (1/4" x 12mm BLK)		4PCS
5	CAP (25 x 25mm SR)		4PCS
6	ALLEN WRENCH (4mm)		1PC


# ITEM: 723139 ASSEMBLY INSTRUCTIONS




**STEP 1** Do not tighten until each step is completed or instructed.




## STEP 2




ITEM: 723139  
ASSEMBLY INSTRUCTIONS  
STEP 3



STEP 4



ITEM: 723139  
ASSEMBLY INSTRUCTIONS  
STEP 5



STEP 6  
COMPLETE

