



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

107931
Dining Tabel

ITEM: **107931**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A GLASS TOP



1PC


B2 (BOX 2)

B LEG



4PCS

C CONNECTION BOX



1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.








ASSEMBLY TIME

10 MINUTES

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 107931 (B2)

1 ALLEN KEY (4MM)		1PC
2 SCREW (M6*10)		4PCS
3 SCREW (M8*10)		8PCS
4 ALLEN KEY (5MM)		1PC
5 ADJUSTING FOOT (Φ20*7*M6*10)		4PCS

HARDWARE PACK IS LOCATED IN 107931 (B2)

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **107931**




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3 **COMPLETE**



Step 3. Now tight screw 2&3 up after stationary.



ITEM:107931

COASTER
FINE FURNITURE

