

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

800702 CONNECT-IT COMPUTER DESK

REVISION 0: 09/26/2017 REVISION 1: 08/14/2019

PAGE 1 OF 14

COASTERFURNITURE.COM

ITEM:800702



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.
 Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

90 MINUTES

PARTS IDENTIFICATION

Α	LEFT SIDE PANEL	1 PC	ı	KEYBOARD SHELF	1 PC
В	RIGHT SIDE PANEL	1 PC	J	BACK PANEL	1 PC
С	MIDDLE DIVIDER PANEL	1 PC	К	BACK PANEL	1 PC
D	CROSS BRACE	1 PC	L	BACK BOARD	1 PC
E	BOTTOM PANEL	1 PC	М	BACK PANEL	1 PC
F	LARGE TOP PANEL	1 PC	N	DOOR	1 PC
G	SMALL TOP PANEL	1 PC	0	LOWER DRAWER FRONT PANEL	1 PC
н	ADJUSTABLE SHELF	1 PC	P	UPPER DRAWER FRONT PANEL	1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:800702



					FINE FORNITORE	
Q	LOWER DRAWER BACK PANEL	1 PC	U	DRAWER SUPPORT		3 PCS
R	UPPER DRAWER BACK PANEL	1 PC	v	DRAWER BOTTOM PANEL		2 PCS
S	LEFT DRAWER SIDE PANEL	2 PCS	w	TOP GLASS	=	1 PC
т	RIGHT DRAWER SIDE PANEL	2 PCS				

Z	z HARDWARE IDENTIFICATION								
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY		
1	GLUE 40g		1 PC	9	SCREW Ø 4x15mm	ATTITUD!	18 PCS		
2	LARGE WOODEN DOWEL Ø 8x30mm		32 PCS	10	PIN Ø 4.9x8mm	6	4 PCS		
3	SMALL WOODEN DOWEL Ø 6x25mm		12 PCS	11	HANDLE L=400mm		3 PCS		
4	CAM LOCK Ø 15x12mm		20 PCS	12	BOLT Ø 4x23mm		9 PCS		
5	CAM BOLT Ø 7x35.5mm		20 PCS	13	POWER OUTLET		1 PC		
6	SCREW Ø 3x12mm		24 PCS	14	HINGE		2 PCS		
7	SCREW Ø 4.5x42mm	AUTUUT (A)	6 PCS	15	HINGE		2 PCS		
8	SCREW Ø 4.3x35mm	attituti.	8 PCS	16	RAIL L = 350mm	CL CR DL DR	2 SET		

NOTE: Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:800702 Q'TY **FIGURE** NO **DESCRIPTION FIGURE** NO **DESCRIPTION** Q'TY **RAIL STICKER** 4 PCS 17 1 SET 20 L = 300mm Ø 20mm **PLASTIC FEET** 18 6 PCS 21 **DOOR CATCH** 1 PC Ø 15mm

22

1 PC

SCREW

Ø 3.5x14.5mm


12 PCS

COASTERFURNITURE.COM


Z11,Z12,Z13,Z14,Z15,Z16,Z17,Z22 not included in blister packaging.


19


SCREW DRIVER





















































PAGE 12 OF 14


16(DR)

COASTERFURNITURE.COM





STEP 19 COMPLETE









ITEM:800702







Note: Dimension tolerance ±5%