

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

650355 **Motion Loveseat**

REVISION 1: 12/30/2019 PAGE 1 OF 3 COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A LEFT BACK	1PC	D BASE	1PC
B RIGHT BACK	1PC	E LEFT EAR	1PC
C MIDDLE BACK	1PC	F RIGHT EAR	1PC

