

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

200974 *Mirror*

REVISION 0 : 03/31/2016 REVISION 1 : 10/29/2018 REVISION 2 : 11/18/2019

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM:200974



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

DRESSER
*FROM BOX ITEM
#200973

C MIRROR SUPPORT
(PACKED WITH DRESSER)

2PCS

HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 32mm - BLK) 8PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





