


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

202411FH
Full Headboard

REVISION 0 : 07/04/2017
REVISION 1 : 01/16/2019
REVISION 2 : 11/22/2019

ITEM: 202411FH



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

AN HEADBOARD
PANEL



1PC

BN LEFT
HEADBOARD
LEG



1PC

CN RIGHT
HEADBOARD
LEG



1PC

HARDWARE IDENTIFICATION

1 BOLT
(M6 x 35mm - BLK)



12PCS

2 LOCK WASHER
(M6 - BLK)



18PCS

3 SMALL FLAT
WASHER
(M6 x 13mm - BLK)



2PCS

4 BIG FLAT
WASHER
(M6 x 19mm - BLK)



16PCS

5 WOOD PLUG



2PCS

6 ALLEN WRENCH
(M4 x 65mm - BLK)



1PC

7 HEX NUT



6PCS

8 WRENCH




1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **202411FH**




ASSEMBLY INSTRUCTIONS

STEP 3
COMPLETE



ITEM: 202411FH



Note : Dimension tolerance $\pm 5\%$