


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

204924
Mirror

REVISION 0 :06/15/2016
REVISION 1 :08/18/2016
REVISION 2 :08/05/2019

ITEM:204924

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A MIRROR




1PC

MIRROR SUPPORT
B (PACKED WITH DRESSER)



2PCS

C DRESSER
FROM BOX
ITEM# 204923



1PC

HARDWARE IDENTIFICATION

1 BOLT
(1/4" x 40mm- RBW)



6PCS

2 LOCK WASHER
(1/4" - RBW)



6PCS

3 FLAT WASHER
(1/4" - RBW)




6PCS

4 ALLEN WRENCH
(4MM - RBW)



1PC

ITEM: **204924**
ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2
COMPLETE

