


# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 460446 Under BedStorage

REVISION 0: 07/09/2019

PAGE 1 OF 5

COASTERFURNITURE.COM

## ITEM:460446



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

### **PARTS IDENTIFICATION**



B CASTER WITH SCREW



4SETS

### **HARDWARE IDENTIFICATION**

1 L BRACKET (50 x 50mm - RBW)



2PCS

3 FLAT WASHER (4 x 16mm - RBW)



4PCS

2 BOLT (1/4 x 15mm - RBW)



4PCS


ALLEN WRENCH (4MM - RBW)



1PC

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




## ITEM:460446

# COASTER

### **ASSEMBLY INSTRUCTIONS**

## STEP2



## ITEM:460446

# COASTER

### **ASSEMBLY INSTRUCTIONS**

# STEP3 COMPLETE

