



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

900210

ACCENT CHAIR WITH OTTOMAN

REVISION 0:06/06/2019

REVISION 1:01/03/2020

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: **900210**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A SEAT AND BACK



1PC

C LEG FOR CHAIR



4PCS

B OTTOMAN



1PC

D LEG FOR OTTOMAN




4PCS

ITEM: **900210**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3



STEP 4



ITEM: 900210



Note: Dimension tolerance $\pm 5\%$