

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

4715 Curio Cabinet

REVISION 0: 04/15/2016 REVISION 0: 06/21/2019

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM: 4715

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


50 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL	1PC	н	DOOR	1PC
В	BOTTOM PANEL	1PC	1	MIRRORED BACK DOWN	1PC
CL	SIDE PANEL/LEFT	1PC	J	MIRRORED BACK UP	1PC
CR	SIDE PANEL/RIGHT	1PC	K	BACK PANEL DOWN	1PC
D	FRONT STRETCHER UP	1PC	L	BACK PANEL UP	1PC
E	FRONT STRETCHER DOWN	1PC	М	LEG	4PCS
F	BACK CROSSBAR UP & DOWN	2PCS	N	GLASS SHELF	5PCS
G	FRONT BOTTOM CROSSBAR	1PC			

HARDWARE IDENTIFICATION


1	CAM-BOLT (Ø6 x 38mm)		10PCS	10	BOLT (5/16" x 3-1/2")]mmmmmmmv	4PCS
2	CAM-LOCK (Ø15mm)		10PCS	11	ALLEN WRENCH (4mm)		1PC
3	WOOD DOWEL (Ø8 x 30mm)		22PCS	12	ALLEN WRENCH (5mm)		1PC
4	BOLT (1/4" x 1-1/2")		12PCS	13	FLAT WASHER (1/4" x 16mm)		12PCS
5	LIGHT LED (Ø65 mm)	9	1PC	14	PALSTIC (8mm)		1PC
6	SCREW (3 x 16mm)	√111111 }}	37PCS	15	L METAL (24 x 13 x 1.5mm)		2PCS
7	LOCK WASHER (5/16")		4PCS	16	PLASTIC LINE (270mm)	\bigcirc	1PC
8	GLASS SUPPORT (Ø6.2mm)		20PCS	17	LARGE SCREW (8 x 25mm)	«mmmm∰	1PC
9	GLUE (20g)		1PC	18	SMALL SCREW (8 x 15mm)	Фишт	1PC




ITEM: **4715 ASSEMBLY INSTRUCTIONS**



STEP 4





STEP 5




ITEM: 4715 ASSEMBLY INSTRUCTIONS

STEP 6





STEP 7 COMPLETE



FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture
This restraint not a substitute for proper adult supervision
This restraint may provide protection against tipping furniture.


Do not allow children to climb on furniture.
Failure to detach this restraint before moveing funiture may
rsult injury and damage



COASTERFURNITURE.COM

ITEM: 4715 ASSEMBLY INSTRUCTIONS





PAGE 6 OF 6

COASTERFURNITURE.COM