

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

600228
Glider And Ottoman

REVISION 0 : 11/23/2012
REVISION 1 : 03/23/2015
REVISION 2 : 06/10/2015
REVISION 3 : 06/10/2019
REVISION 3 : 10/24/2019

ITEM: **600228**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME





30 MINUTES

ITEM: **600228**






ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION



HARDWARE PACKAGE




ITEM: **600228**




ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **600228**




ASSEMBLY INSTRUCTIONS
STEP 3



STEP 4
COMPLETE



ITEM: **600228**



Note : Dimension tolerance $\pm 5\%$