


# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

700295 3 PC Occasional Set

REVISION 0 : 06/18/2016 REVISION 0 : 08/28/2019

PAGE 1 OF 5

COASTERFURNITURE.COM

### ITEM: 700295

#### **ASSEMBLY INSTRUCTIONS**




#### **ASSEMBLY TIPS:**

- Remove hardware from box and sort by size.
  Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


40 MINUTES

#### **PARTS IDENTIFICATION**

Α	COFFE TABLE (B2) 1PC	E END TABLE (B2)	2PCS
В	COFFE TABLE (B1) 1PC	F TOP FRAME (B1)	2PCS
С	COFFE TABLE (B1) 1PC UPPER LEG	G END TABLE (B1)	2PCS
D	COFFE TABLE (B1) 1PC	H END TABLE (B1)	2PCS

#### **HARDWARE IDENTIFICATION**

1	ALLEN WRENCH (5 mm)	1PCS	4	LOCK WASHER (5/16")	15PCS
2	BOLT (5/16" x 1-3/4")	12PCS	5	FLAT WASHER (5/16" x 22mm)	15PCS
3	BOLT (5/16" x 2")	3PCS	6	SUCTION (Ø35mm)	12PC




# ITEM: **700295**


#### **ASSEMBLY INSTRUCTIONS**

STEP 3




STEP 4






### STEP 5



### STEP 6



PAGE 3 OF 5

COASTERFURNITURE.COM


# ITEM: **700295**


#### **ASSEMBLY INSTRUCTIONS**

STEP 7










#### STEP 9 COMPLETE





# ITEM: **700295**ASSEMBLY INSTRUCTIONS



