

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

950156 Console Table

REVISION 0: 12/09/2016

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: **950156**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

TOP FAME A



1PC

C **LEFT LEG**



2PCS

BOTTOM PANEL В



1PC

RIGHT LEG



2PCS

HARDWARE IDENTIFICATION

BOLT 1 (1/4" x 1/2")

LARGE L METAL (60 x 60 x 2.0mm)

SMALL L METAL 3 (270mm)

SCREW 4 (3 x 14mm)

> **ALLEN WRENCH** (4mm)



16PCS



4PCS



4PCS




8PCS



1PC

PALSTIC 6 (8mm)





LARGE SCREW 9 (8 x 25mm)

SMALL SCREW 10 (8 x 15mm)



1PC

1PC

2PCS

Community

∯mm⊳

COASTERFURNITURE.COM


1PC


1PC

STEP 1

5

STEP 2







ITEM: **950156**ASSEMBLY INSTRUCTIONS




STEP 3





STEP 5 COMPLETE



FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture
This restraint not a substitute for proper adult supervision
This restraint may provide protection against tipping furniture.

Do not allow children to climb on furniture.

Failure to detach this restraint before moveing funiture may rsult injury and damage



COASTERFURNITURE.COM

ITEM: **950156**ASSEMBLY INSTRUCTIONS



