

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**950187**  
***Curio Cabinet***

ITEM: **950187**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!














1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

















ASSEMBLY TIME

50 MINUTES

## PARTS IDENTIFICATION

A	TOP PANEL		1PC	H	BACK TOP AND BOTTOM CROSSBAR		2PCS
B	SIDE PANEL/LEFT		1PC	I	BACK MIDDLE CROSSBAR		1PC
C	SIDE PANEL/RIGHT		1PC	J	BACK PANEL		2PCS
D	GLASS DOOR		1PC	K	MIRROR		2PCS
E	BOTTOM PANEL		1PC	L	LEG		4PCS
F	FRONT UPPER CROSSBAR		1PC	M	GLASS SHELF		4PCS
G	FRONT BOTTOM CROSSBAR		1PC				

## HARDWARE IDENTIFICATION


1	BOLT (1/4" x 1-1/2")		16PCS	8	SHELF SUPPORT (Ø6.2mm)		16PCS
2	CAM-BOLT (Ø6 x 38mm)		12PCS	9	GLUE (20g)		1PC
3	CAM-LOCK (Ø15mm)		12PCS	10	PALSTIC (8mm)		1PC
4	FLAT WASHER (1/4" x 19mm)		16PCS	11	L METAL (24 x 13 x 1.5mm)		2PCS
5	LIGHT LED (Ø65 mm)		1PC	12	PLASTIC LINE (270mm)		1PC
6	ALLEN WRENCH (4mm)		1PC	13	LARGE SCREW (8 x 25mm)		1PC
7	BACK PANEL SCREW (3 x 16mm)		36PCS	14	SMALL SCREW (8 x 15mm)		1PC

ITEM: **950187**




**ASSEMBLY INSTRUCTIONS**

**STEP 1**



**STEP 2**




ITEM: **950187**




**ASSEMBLY INSTRUCTIONS**


**STEP 3**



**STEP 4**




**STEP 5**




ITEM: **950187**

**ASSEMBLY INSTRUCTIONS**

STEP 6




STEP 7



ITEM: **950187**

## ASSEMBLY INSTRUCTIONS

### STEP 8





**COASTER**  
FINE FURNITURE

### STEP 9 COMPLETE

#### FURNITURE TIPPING RESTRAINT

##### WARNING

Injury may result from tipping furniture.  
This restraint not a substitute for proper adult supervision.  
This restraint may provide protection against tipping furniture.  
Do not allow children to climb on furniture.  
Failure to detach this restraint before moving furniture may result injury and damage.



ITEM: **950187**

**ASSEMBLY INSTRUCTIONS**

