



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



601926
GLIDER RECLINER

ITEM: 601926

ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠ WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2.This product is for home use only and not intend for commercial establishment.






ASSEMBLY TIME PER UNIT: 10 MINUTES


PARTS IDENTIFICATION

A		BASE	1PC
B		BACK	1PC
C		LEFT EAR	1PC
D		RIGHT EAR	1PC

ITEM: 601926

ASSEMBLY INSTRUCTIONS





Note : Dimension tolerance $\pm 5\%$