



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

502812
LOVESEAT

ITEM : 502812

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1.Don't attempt to repair or modify parts that are broken or defective.
Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

(A)  BACK 1PC


(B)  SEAT 1PC

(C)  FOOT 4PCS


ITEM : 502812
ASSEMBLY INSTRUCTIONS





STEP 1



STEP 2




STEP 3



502812

COASTER
FINE FURNITURE



Note: Dimension tolerance $\pm 5\%$

