

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

120451 *BAR TABLE*

REVISION 0: 08/25/2017 REVISION 1: 09/08/2020

PAGE 1 OF 10




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 55 MINUTES

PARTS IDENTIFICATION

A	TOP GLASS	1PC
В	SIDE BOARD	2PCS
С	TOP BOARD	1PC
D	BASE AND MIDDLE SHELF	3PCS
E	BOTTLE RACK	2PCS
F	DRAWER FRONT PANEL	2PCS
	DACE O CE 40	
	PAGE 2 OF 10 COASTERFURNITURE	

DRAWER SIDE PANEL G 2PCS Н DRAWER BOTTOM PANEL 1PC TOP GLASS SUPPORT BAR 1PC **CENTER SUPPORT WOOD** J 1PC Κ **CENTER SUPPORT METAL** 1PC L **CENTER SWIVEL PART** 1PC TOP GLASS SUPPORT LEG 1PC М

PAGE 3 OF 10

N GLASS HOLDER




2PCS

HARDWARE IDENTIFICATION


1 CAM-BOLT (38mm) 20PCS 9 LARGE ALLEN KEY (5mm) 1PC 2 LARGE CAM-LOCK (\$\psi\$15mm) 16PCS 10 SCREW (7\psi x 5/8") 14PCS 3 LARGE ALLEN BOLT (5/16" x 2-1/2" SR) 2PCS 11 FLOOR PROTECTOR (\$\psi\$30mm) 4PCS 4 PLASTIC WASHER (5/16" x 50mm) 1PC 12 GLUE 1PC 5 SMALL CAM-BACK (\$\psi\$15 x 9.5mm) 6PCS 6 SMALL WASHER (5/16" SR) 2PCS 14 LARGE WASHER (5/16" x 50mm) 2PCS 7 SPRING WASHER (5/16" SR) 2PCS 15 LABEL 4PCS									
3 LARGE ALLEN BOLT (5/16" x 2-1/2" SR) 4 PLASTIC WASHER (5/16" x 50mm) 5 SMALL CAM-BACK (φ15 x 9.5mm) 6 SMALL WASHER (5/16" SR) 6 SMALL WASHER (5/16" SR) 7 SPRING WASHER (Φ2PCS 15 LAREI (7# x 5/8") 11 FLOOR PROTECTOR (φ30mm) 12 GLUE 1PC 12 GLUE 1PC 14 LARGE WASHER (5/16" x 50mm) 2 PCS 15 LAREI (4 PCS 4 PCS 4 PCS	1		02 M	20PCS	u //	1PC			
(5/16" x 2-1/2" SR) (# 30mm) 4 PLASTIC WASHER (5/16" x 50mm) 5 SMALL CAM-BACK (#15 x 9.5mm) 6 SMALL WASHER (5/16" SR) 2 PCS 7 SPRING WASHER 2 PCS 1 (# 30mm) (# 30mm) (# 30mm) 1 PC 12 GLUE 13 SMALL ALLEN BOLT (1/4" x 12mm SR) 6 PCS (5/16" x 50mm) 2 PCS 14 LARGE WASHER (5/16" x 50mm) 2 PCS 4 PCS	2			16PCS		14PCS			
5 SMALL CAM-BACK (Ø15 x 9.5mm) 8 4PCS 13 SMALL ALLEN BOLT (1/4" x 12mm SR) 6PCS (1/4" x 12mm SR) 6 SMALL WASHER (5/16" SR) 2PCS 14 LARGE WASHER (5/16" x 50mm) 2PCS (5/16" x 50mm) 7 SPRING WASHER 2PCS 15 LARGE (5/16" x 50mm) 4PCS	3			2PCS	(C)	4PCS			
6 SMALL WASHER (5/16" SR) 2PCS 14 LARGE WASHER (5/16" x 50mm) 7 SPRING WASHER 2PCS 15 LARGE 4PCS	4		•	1PC	12 GLUE	1PC			
(5/16" SR) (5/16" x 50mm) (5/16" x 50mm) 4PCS	5		9	4PCS		6PCS			
	6		o	2PCS	(0)	2PCS			
	7			2PCS	15 LABEL	4PCS			
8 WOOD DOWEL 20PCS 16 SMALL ALLEN KEY (4mm) 1PC	8			20PCS	10	1PC			



STEP 1




STEP 2




PAGE 5 OF 10



STEP 3




STEP 4






STEP 5




STEP 6




PAGE 7 OF 10



STEP 7




STEP 8




PAGE 8 OF 10




STEP 9



STEP 10 COMPLETE








COASTERFURNITURE.COM

PAGE 9 OF 10





Note: Dimension tolerance ±5%